





MC110 PRO/MC120 PRO pH Monitors

PRO pH monitor allows you to continuously monitor pH values directly in your reservoir. Features include: user selectable set point, visual LED alarm when values go above or below the set point and manual calibration. Each monitor is powered by a 12 VDC adapter and is ideal for applications such as Hydroponics and Aquarium.

The pH monitors are very simple to operate:

1. Hang your monitor above the reservoir;
2. Connect the adapter to the meter and plug in the power supply (make sure that your power supply is in a safe area away from the water);
3. Immerse 2/3 of the electrode in the solution;
4. The probe can now remain there permanently.

The monitors are supplied complete with a MA911B/2 pH electrode. Each monitor comes complete with a 12 VDC adapter and calibration solution.

Specifications	MC110 PRO	MC120 PRO
		
Range	0.0 to 14.0 pH	0.0 to 14.0 pH
Resolution	0.1 pH	0.1 pH
Accuracy (@25°C)	±0.2 pH	±0.2 pH
Calibration	manual, 2 points through trimmers on the meter front panel	manual, 2 points through trimmers on the meter front panel
Set point	3.5 to 7.5 pH	5.5 to 9.5 pH
Alarm	active when measurement is higher or lower than selected set point	active when measurement is higher or lower than selected set point
pH Electrode	MA911B/2 (included)	MA911B/2 (included)
Environment	0 to 50°C / 32 to 122°F; max RH 95%	0 to 50°C / 32 to 122°F; max RH 95%
Power supply	12 VDC power adapter (included)	12 VDC adapter
Packaging dimensions	268 x 122 x 118 mm	268 x 122 x 118 mm
Packaging weight	820 g	820 g

Accessories



- M10000B Electrode rinse solution, 20 mL sachet (25 pcs)
- M10004B pH 4.01 buffer solution, 20 mL sachet (25 pcs)
- M10007B pH 7.01 buffer solution, 20 mL sachet (25 pcs)
- M10010B pH 10.01 buffer solution, 20 mL sachet (25 pcs)
- M10016B Electrode cleaning solution, 20 mL sachet (25 pcs)
- MA9015 Electrode storage solution, 20 mL sachet (25 pcs)
- MA9016 Electrode cleaning solution, 20 mL sachet (25 pcs)
- MA9310 12 VDC Adapter, 220 V
- MA9311 12 VDC Adapter, 110 V
- MA911B/2 Double junction, gel filled pH electrode with 2 m cable



User selectable Hi/Low Set Point

A visual LED alarms when value goes above or below the set point the user selected.



Ordering Information

MC110 PRO is supplied complete with MA9310 12VDC adapter, MA911B/2 pH electrode, 20 mL pH 7.01 sachet of calibration solution, calibration screwdriver and instructions, in a carton box.

MC120 PRO is supplied complete with MA9310 12VDC adapter, MA911B/2 pH electrode, 20 mL pH 7.01 sachet of calibration solution, calibration screwdriver and instructions, in a carton box.

DISTRIBUTOR: -

BLUE HORIZON

Gopal Niwas, 135, Princess Street Mumbai-400002 INDIA

Tel: +91 9820206611 Email: sales.bluehorizon@gmail.com

